


Rechargeable Battery

Owner's Manual




Connecting The Battery

If your fountain came with an A/B/C/D Control Button, use the instructions below:




Step 1: In the open battery compartment, you will see three cords hanging down that you must connect to the connection port.

If you do not see the three cables inside the battery compartment, reach up into the base and gently pull them down until they are hanging inside the battery compartment.




Step 2: Using the cords from inside the base and the cord from the battery, connect the color coded cords to their corresponding receptacles on the connection port.

Use the diagram below for more help on connecting the battery. (Illustration 1.2)






Step 3: Place your connection port inside the designated angled area located at the back of your fountain base. (See illustration 1.1 below)




Step 4: Place the battery inside of the compartment in front of the connection port. (See illustration 1.1)

DO NOT PLACE BATTERY UPSIDE DOWN INSIDE THE BATTERY COMPARTMENT.



Connecting The Battery

If your fountain came with an A/B Control Button, use the instructions below:




Step 1: In the open battery compartment, you will see two cords hanging down that you must connect to the connection port.

If you do not see the two cables inside the battery compartment, reach up into the base and gently pull them down until they are hanging inside the battery compartment.




Step 4: Place the battery inside of the compartment in front of the connection port. (See illustration 2.1)

DO NOT PLACE BATTERY UPSIDE DOWN INSIDE THE BATTERY COMPARTMENT.




Step 2: Using the cords from inside the base and the cord from the battery, connect the color coded cords to their corresponding receptacles on the connection port.



Use the diagram below for more help on connecting the battery. (Illustration 2.2)



Step 3: Place your connection port inside the designated angled area located at the back of your fountain base. (See illustration 2.2)



2.2



IMPORTANT BATTERY SAFETY INSTRUCTIONS

DANGER: Do not store battery in an airtight container as it may cause an explosion.

PROPOSITION 65 WARNING: Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Wash hands after handling.

WARNING: When using electric devices, basic safety precautions should always be followed to reduce the risk of fire, electric shock and personal injury, including the following:

WARNING:

1. Do not incinerate the battery even if it is severely damaged or is completely worn out. The battery can explode in a fire. Check with municipal codes in your area for possible special disposal instructions.
2. If liquid leaks from the battery cell, discontinue use immediately and dispose of properly.
3. Do not charge battery in rain or in wet location.
4. Never attempt to open the battery for any reason. If the plastic housing of the battery breaks or cracks, immediately discontinue use and do not recharge. If the battery appears to be dusty or dirty, wipe it off with a soft cloth.
5. Use only the included battery. Contact our customer care line for a replacement at 888-648-2011.
6. Do not attempt to disassemble, remodel or destroy the battery, as it may cause battery leakage, fire, or bursting; and could also create sulfuric acid spills from the battery resulting in possible burns to person and damage to the immediate environment.
7. Exercise care in handling batteries in order not to short the battery with conducting materials such as rings, bracelets or keys. The battery or conductor may overheat and cause burns.
8. The battery contains diluted sulfuric acid, a very toxic substance. If the battery leaks and the liquid inside spills on the skin or clothing, immediately wash it off with plenty of clean water. If the liquid splashes into eyes, immediately flush the eyes with plenty of clean water and consult a doctor. Sulfuric acid in the eyes may cause loss of eyesight and acid on the skin will cause burns.
9. Charge battery using the specified charger and under the charging conditions as specified. Charging the battery under any other conditions may cause the battery to overheat, emit hydrogen gas, leak, ignite or burst.
10. When this product is not used for 30 days or more, remove the battery from the fountain, charge it fully and store in a place where humidity is low. Do not store the battery under direct sunlight or in high temperatures. Unsatisfactory storage conditions may cause deterioration in battery performance, and may shorten the service life.
11. When charging the battery always do so in a well ventilated area and where you can observe the charging process.
12. Never dispose of batteries in the garbage. Disposal of batteries in the garbage is unlawful under state and federal environmental laws and regulations. Always take used batteries to your local battery-recycling center.
13. **DO NOT CHARGE ON COUNTER TOPS, CARPETS OR OTHER FINISHED SURFACES. IT IS RECOMMENDED THAT THE BATTERY BE PLACED ON A CONCRETE SURFACE WHILE CHARGING.**